

TM6™ UNBOXING GUIDE



My Thermomix® TM6™ is here! ♥

What now?

1. Remove it from the box (always lifting it from the handle, NOT from the arms, and DO NOT drag it).

Check that the following accessories are included:

- a) Varoma dish/ varoma tray / varoma lid
- b) Spatula
- c) Simmering basket
- d) Butterfly whisk
- e) Splash guard
- f) Mixing bowl, mixing bowl lid and measuring cup

Note:

Keep the box for possible return or shipment.

2. Plug the TM6™ in and let it run the first factory update.

3. Set it up with the UNITED STATES as country of residence.

4. If you haven't been connected automatically to the Internet, do so by accessing your Wi-Fi like this:

- Tap the 3 small lines in the top left corner of the Thermomix® screen
- Click Settings
- Click Wi-Fi

5. A second update may start and it could take a little longer to finish (up to 30 minutes). DO NOT interrupt the process. Don't move your TM6™ or disconnect it. Be patient.

6. If you haven't opened your Cookidoo® account, go to your computer, iPad, or cell phone, log in to <https://cookidoo.thermomix.com/foundation/en-US> and sign up. Make sure you don't do it in trial mode.

7. When prompted by the TM6™, enter your Cookidoo® account and password.

8. And that's it! Talk to your consultant and schedule the appointment for your "Virtual Delivery" where you will learn more about the TM6™'s use and care.

9. CONGRATULATIONS! A world of delicious possibilities awaits you ♥